


Log Balance Beam Surface Mount Installation Instructions



SPECIFICATIONS AND DESCRIPTION - 4', 6', 8'

Manufactured from color integrated Glass Fiber Reinforced Concrete (GFRC) over structural steel frame. Glass fiber is Alkali Resistant (AR) type glass formulated for concrete. GFRC shall be 1,500 pounds per square inch in tension, 5,000 pounds per square inch in compression. Hardened GFRC is colored with an integral color on the inside of the log remainder of log is sealed with a V-Seal. Final coloring is achieved with latex stain made for concrete. GFRC is readily repairable no matter the age of the material.

The estimated delivery date will be confirmed within 24 hours prior to shipping. If delivery date is changed a service charge of 10% of the shipping charge will be added to the rescheduled shipping.

It is the responsibility of the installation contractor to coordinate with the driver to insure timely offloading. The truck will remain on-site for 2 hours after the appointed delivery time. After this period there would be a fee of \$50 per hour for

Log Balance Beam Surface Mount Installation Instructions

INSTALLATION

Read installation instructions thoroughly before starting installation process.

STEP 1: Log Crawl is shipped in on piece to site. Attach Leg plates with bolts provided. Utilize foam or other means to protect log from damage when moving Log into place. Carefully place Log into final installation location. Mark center of hole on mounting plate.


STEP 2: Select a carbide drill bit with a diameter equal to the anchor diameter. Drill hole to any depth exceeding the desired embedment.

STEP 3: Clean hole or continue drilling to accommodate drill fines. (concrete dust) - Please wear eye protection.

STEP 4: Drive the anchor into the hole through material being fastened until washer is flush with material being mounted. Expand anchor by tightening the nut or head 2 to 3 turns.

NOTE: Bracing material may be required during assembly. Place a brick or equivalent at the bottom of ground holes to provide a solid foundation. Allow for this in hole depth.

NOTE: Shock absorbing properties of safety surfacing materials vary. A soft, resilient surface should be placed around all climbers, extending at least eight feet in all directions surrounding the climber. **NEVER INSTALL PLAY EQUIPMENT ON CONCRETE OR ASPHALT.** A fall on a hard surface can result in serious injury to the equipment user.



Shock
 Absorbing
 Material

